

SECU4 Bags™

User manual



*Your best protection
against theft and loss*

(Windows Mobile 6)

Made for

 iPhone  iPad

www.secu4.com

Warranty

SCOPE OF THE WARRANTY

Subject to legal provisions, the responsibility of SECU4 under this warranty is limited to the provisions set out below: SECU4 warrants that this product is safe from material and manufacturing defects under normal conditions of use for a period of TWO (2) YEARS from the date of end-user purchase. If a product defect is encountered within the warranty period and a valid claim is lodged, SECU4 will replace the product with either a new complete unit or with a new accessory if the default found is limited to an ancillary product.

When a product or an accessory is replaced, it becomes the property of the buyer and the product or accessory exchanged becomes the property of SECU4. The warranty accorded to the exchanged product will not exceed the original warranty.

EXCLUSIONS AND LIMITATIONS

This limited warranty applies only to hardware products manufactured by or on behalf of SECU4 which can be identified by the trademark, trade name or SECU4 logo which is affixed on them. The software distributed by SECU4 without or under the trade name SECU4 (including, but not limited to, system software) is not covered by this limited warranty. Kindly refer to the accompanying software license agreement accompanying the software for details of your rights concerning its use.

SECU4 does not warranty that the operation of the product will be uninterrupted or error-free. SECU4 is not liable for damage resulting from non-compliance with usage guidelines of the product.

This warranty does not apply to: (a) any damage caused by the use of products other than those in the SECU4 recommended usage guidelines (b) any damage caused by accident, abuse, misuse, flooding, fire, earthquake or other external causes, (c) any damage caused by the operation of the product outside the foreseeable and permitted usage guidelines issued by SECU4 (d) any damage caused by any intervention (including upgrades and extensions) by any person who is not a representative of SECU4 or a SECU4-approved service provider (e) a product or a component which has been tampered with so that it significantly alters the functionality or capabilities without the written permission of SECU4 (f) consumable items such as batteries, unless the damage is caused by a material or workmanship defect (g) a product on which any SECU4-related serial number has been removed or defaced.

IN SO FAR AS THE LAW SO AUTHORISES, THE WARRANTY AND APPEALS SET OUT ABOVE ARE EXCLUSIVE AND PREVAIL OVER ALL OTHER CONTRACTUAL WARRANTIES, REMEDIES AND CONDITIONS, WHETHER WRITTEN OR ORAL, LEGAL, EXPRESSED OR IMPLIED, WITHIN THE PURVIEW OF THE APPLICABLE LAW. SECU4 EXPRESSLY DISCLAIMS ALL IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND GUARANTEES OF HIDDEN AND LATENT DEFECTS. WHEN SECU4 IS LEGALLY PRECLUDED FROM REJECTING ANY EXPRESSED OR IMPLIED WARRANTIES, THEN TO THE EXTENT PERMITTED BY LAW, THE STATED WARRANTIES SHALL BE LIMITED TO THE DURATION OF THIS GUARANTEE AND THE PROVISION OF A REPAIR OR REPLACEMENT WHICH IS DETERMINED BY THE SOLE DISCRETION OF SECU4. No dealer, agent or employee of SECU4 is empowered to modify, extend or supplement this guarantee.

UNLESS SO PROVIDED IN THIS WARRANTY AND TO THE EXTENT PERMITTED BY THE LAW, SECU4 IS NOT LIABLE FOR ANY DIRECT, SPECIAL, INCIDENTAL OR INDIRECT DAMAGE RESULTING FROM ANY MATERIAL LOSS, ANY LOSS OF INCOME, ANY ACTUAL OR FORESEEABLE LOSS OF PROFITS (INCLUDING ANY LOSS OF PROFITS RELATED TO CONTRACTS), ANY LOSS OF FINANCIAL OPPORTUNITY, ANY FORESEEABLE ECONOMIC LOSS, ANY LOSS OF BUSINESS, LOSS OF OPPORTUNITY, LOSS OF CLIENTELE, ANY LOSS OF REPUTATION, ANY LOSSES, DAMAGE, ANY INDIRECT OR CONSEQUENTIAL DAMAGE WHATSOEVER, INCLUDING THE REPLACEMENT OF EQUIPMENT OR GOODS, ANY COSTS OF RECOVERY. THIS LIMITATION DOES NOT APPLY TO CLAIMS IN CASE OF INJURY OR DEATH.

HOW TO OBTAIN SERVICE UNDER WARRANTY?

The buyer is kindly requested to access our online support as indicated in the documentation and on the physical product itself before seeking a warranty service.

If the product is still not working properly after using the solutions provided, the buyer is kindly requested to contact the representatives of SECU4 or, where appropriate, a service provider approved by SECU4 and whose address is contained in the documentation or on the SECU4 website. A SECU4 representative or its authorised service provider will help determine if the product requires a service and, if so, the buyer will be informed how SECU4 will provide this service. SECU4 or its recognised service provider will provide a service under warranty on products that are submitted or presented for service only during the warranty period, to the extent permitted by law. The cost of shipping and transportation will be at the buyer's expense if the product cannot be repaired in the country where the buyer is located. Pursuant to the applicable law, SECU4 may require the buyer to furnish proof of purchase and/or to comply with registration formalities before receiving a service warranty.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

15.21 Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

15.105 NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Table of contents

Warranty.....	2
Introduction	3
Security information.....	3
Quick start.....	4
Symbols on your SECU4Bags™	8
Application icons	9
Contact.....	9
Declaration of conformity.....	10

Introduction

SECU4Bags™ is a mobile alarm system for protection of your valuables such as wallets, bags, laptops, etc.

SECU4Bags™ works via an application downloaded to your mobile phone* equipped with Bluetooth® functionality.

Security information

- ▶ The maximum sound level of the alarm is higher than 100db. Under no circumstances should SECU4Bags™ be brought too close to your ear. It is likely to inflict irreversible damage to your hearing.
- ▶ Abide by the laws and local restrictions on the use of SECU4Bags™ e.g. in planes or in hospitals.
- ▶ Under no circumstances should SECU4Bags™ housing card be opened. The batteries included can cause significant damage to your health.
- ▶ Do not let the children handle your SECU4Bags™ without close surveillance.

* mobile phone or any other electronic device which is compatible with your SECU4Bags™

Quick start

1 Compatibility test and software installation

Test your mobile phone's* compatibility using its wireless Internet connection.

NOTE: Where available, the dedicated application can be downloaded from your smartphone's application store. Search for "SECU4Bags™"

NOTE: If your mobile phone* does not have wireless Internet access, proceed to step 1.4.

1.1 Compatibility test via SMS (for EU)

- ▶ Send an SMS from your mobile phone* with the short text "BAGS" to +44 762 480 0482.
- ▶ Open the link received to test the compatibility.
- ▶ If your mobile phone IS compatible, a FREE application will download automatically via your wireless Internet connection (local cellular data transfer rates apply).

1.2 Compatibility test via INTERNET

- ▶ Open your mobile phone's* Internet browser.
- ▶ In the address bar enter the following link : <http://t.secu4.com>.
- ▶ Press Send/Enter/Get Link to access the <http://t.secu4.com> website.
- ▶ The <http://t.secu4.com> mobile phone* testing site will then verify if your mobile phone* is compatible with your SECU4Bags™.
- ▶ Your SECU4Bags™ will NOT work with your mobile phone* if your screen displays "Unfortunately your mobile phone* is not compatible".
- ▶ If your mobile phone* IS compatible, a FREE application will download automatically via your wireless Internet connection (local cellular data transfer rates apply).
- ▶ The SECU4Bags™ application will appear in your product Application Menu.
- ▶ Proceed to step 2 (setting up the card).

* mobile phone or any other electronic device which is compatible with your SECU4Bags™

1.3 Compatibility test via a QR (Quick Response) CODE scan

- ▶ If your mobile phone* has a bar code scanner software, you can test it by scanning this picture. The code contains the Internet link.





1.4 Compatibility test and installation via COMPUTER



- ▶ Kindly access our website homepage www.secu4.com to verify the compatibility of your mobile phone* and to download the application.
- ▶ Follow the instructions of the website.

2 Setting up your SECU4Bags™

Before first use – IMPORTANT

- ▶ Charge your SECU4Bags™ on your computer via the USB cable included or by using the travel USB socket charger (use the one supplied with your mobile phone or purchase separately).
- ▶ The top light  flashes. The charging time is approximately 3 hours.
- ▶ During the initial charge, it is advised not to disconnect your SECU4Bags™ before the flashing light  completely switches itself off.



Activation of your SECU4Bags™

- ▶ Press the on/off side button  for 1 second.
- ▶ The bottom icon  illuminates.
- ▶ To switch off your SECU4Bags™, keep the on/off side button pressed for 3 to 5 seconds.

* mobile phone or any other electronic device which is compatible with your SECU4Bags™

3 Activation of the protection

On your SECU4Bags™

- ▶ Press your SECU4Bags™ on/off side button  for 1 second.
- ▶ The icon  illuminates.

On your mobile phone*

- ▶ Open the mobile phone application “SECU4Bags™”. Accept the Bluetooth® permission request.

Note 1: If your Bluetooth® is already turned on, there won't be a Bluetooth® request

Note 2: If you encounter a problem, refer to the user manual of your mobile phone* or on the SECU4 website www.secu4.com.





- ▶ Click on the welcome screen of the application.
- ▶ The application looks for your SECU4Bags™ via Bluetooth® wireless technology.
- ▶ Enter the pairing code “0000”.

Note 1: The search time for your SECU4Bags™ can take up to 1 minute.

Note 2: If your SECU4Bags™ is not recognised, ensure that it is turned on and operating.

Note 3: If several SECU4Bags™ cards are located within a close range, make sure that no other SECU4Bags™ is turned on at the same time.

Note 4: You only need to pair your SECU4Bags™ and your mobile phone* once.





- ▶ The icon  on your SECU4Bags™ blinks.
- ▶ Click on the “Start protection” application icon  on your mobile phone*.
- ▶ The icon  on your SECU4Bags™ blinks.
- ▶ The protection is active, the “Protecting” icon  appears on your mobile phone*.
- ▶ Slip your SECU4Bags™ into the object you want to protect and keep your mobile phone* near you.


Notes:

- Do not put your mobile phone* in the protected object.
- Avoid inserting your SECU4Bags™ inside metal objects or very close to objects that could disrupt the Bluetooth® signal emission (key, magnet, etc.).

* mobile phone or any other electronic device which is compatible with your SECU4Bags™


The object in which you have inserted your SECU4Bags™ is now protected. The default protection parameters are:

-  Protection zone: distance = middle (about 10 to 15 meters, 33 to 50 feet)
-  Alarm time delay: 5 seconds
-  Alarm volume level on your SECU4Bags™: level 3 (~80dB)
-  Alarm on your mobile phone*: ringing and vibrating

If your protected object is moved out of the protection zone, your mobile phone* will ring and/or vibrate and display an alarm icon . You will then have a few seconds to react and return to the protection zone. After that delay and if enabled, the alarm be activated on your SECU4Bags™ and protect the object in which it is inserted.

If the alarm goes off by mistake you can disable it by pressing the alarm icon  on your mobile phone* when you are inside the protection zone.

If your SECU4Bags™ alarm goes off, it will be automatically turned off when you re-enter the protection zone.


Tap the icon  on your mobile phone* to exit the application. Your SECU4Bags™ will then automatically turn itself off.

IMPORTANT!

1. For optimal performance keep your SECU4Bags™ more than 20cm away from your mobile phone*.
2. Do not use your SECU4Bags™ when the battery is exhausted. Its effectiveness is reduced and the frequency of false alarms increases.
3. Do not use your SECU4Bags™ in airplanes or other places that require your mobile phone* to be switched off.
4. During surveillance of persons, set the alarm volume to a minimum or to silent.

* mobile phone or any other electronic device which is compatible with your SECU4Bags™

Symbols on your SECU4Bags™









1. On/off top button

- ▶ Press this button for 1 second to activate your SECU4Bags™.
- ▶ Press for 3 to 5 seconds to turn it off.





2. Charge via USB port

- ▶ Connect the USB cable provided with your SECU4Bags™ on a computer or a travel charger. Recharge the batteries system until the battery blinking light goes out.


3. Batteries

- ▶   (Fast flash) Battery level is low! Recharge your SECU4Bags™ as soon as possible.
- ▶   (Slow flash) SECU4Bags™ is on charge.
- ▶   (No flashing light) The recharge of your SECU4Bags™ is complete. Refer to the SECU4Bags™ battery level indicator on your mobile phone* to check the current battery level of your SECU4Bags™ card.

4. Protection/Alarm




- ▶   SECU4Bags™ is in protection mode.
- ▶   SECU4Bags™ is in alarm mode.

5. Activation/Connection





- ▶   SECU4Bags™ is on.
- ▶   SECU4Bags™ is connected to the mobile phone*.



* mobile phone or any other electronic device which is compatible with your SECU4Bags™

Application icons

-  SECU4Bags™ is connected. By tapping on this icon, you can start the protection.
-  Object under surveillance. By tapping on this icon, you can stop the protection.
-  In case of an alert, you are warned by this icon. You can stop the alarm by tapping on this icon.

Settings icons (click on the icons to select the various possible settings):

-  Protection distance: near, middle, far.
-  Time delay for alarm activation on your SECU4Bags™ following the receipt of an alert on the mobile phone: 1 to 15 sec.
-  Sound level of the alarm: choice of 5 different levels.
-  Type of alarm on your mobile phone*: ringing and vibrating, or vibrating only.

For more details about how to connect your SECU4Bags™, tap the icon  on the welcome screen to view the help video. Once your SECU4Bags™ is connected, tap on the icon  for a quick help guide.

A demonstration film/video is also available at www.secu4.com.

Contact

For more information on SECU4Bags™ or for any other information, please visit our website at www.secu4.com.

Warranty

The warranty period may vary depending where you live. Otherwise, the warranty period is set at two years from the date of purchase.

The SECU4Bag™ is an effective aid against theft but does not entirely replace your vigilance

- Don't leave your luggage and valuables unattended.
- Don't leave your valuables in sight for all to see.
- Do not forget to turn off your SECU4Bags™ at airport check-ins or in any other place where it is required to switch off mobile phones.
- SECU4 disclaims any liability for loss or theft of objects of end-users of the SECU4Bags™ system.

Technical Specifications:

Format: 78 mm × 48 mm × 5.2 mm
(3" × 1 9/10" × 2/10")

Energy supply: Accumulator Li-Po 3.7V

Recharge: via the USB cable

Active standby: up to 120 hours

Communication protocol: Bluetooth®

Sound level: >100dB

* mobile phone or any other electronic device which is compatible with your SECU4Bags™



DECLARATION OF CONFORMITY

Name and address of the manufacturer or his authorized representative established in the Community:

**SECU4
Technopôle 5
3960 Sierre
Switzerland**

Description of the equipment:

**SECU4Bags™
Personal mobile alarm system**

Reference to the Standards which have been applied:

EMC 89/336/EEC (Emissions and Immunity Compliance)

**IEC 61000-4-2 : 2006
Immunity for residential,
commercial and light industry
(ESD, Electrostatic discharge)**

**IEC 61000-6-3 : 2008
Emission for residential,
commercial and light industry
(radiated emission, conducted
emission)**

Reference to conformity:

**HEVS, Switzerland
Test report No Cos dated of
23th December 2008**

**I hereby certify that the SECU4Bags™, Personal mobile alarm system,
conforms to the requirements of the EMC Directive 89/336/EEC**

A handwritten signature in blue ink, appearing to read "Ralph Rimet".

**Ralph Rimet
CEO SECU4
Dated 9th March 2011**